

Eddy's Boilerhouse News

TIP OF THE MONTH FOR THE MAINTENANCE DEPARTMENT

By Eddy Emerson

In all the training classes no one has ever asked for a list of Flame Signal Reading until this year. And, I thought it was such a good idea that I decided to post them on my news letter. So here they are:

Flame Signal Reading

FIREYE CONTROLS

UVM Series	4.0 – 5.5 VDC
TFM Series	14 – 17 VDC
D – 10/20/30 Series	16 – 25 VDC
E-100 / E110 Series	10 Minimum 20 – 80 Normal
E100 / E110 Series w/ EPD Programmer	4 – 10 VCD
M-Series II	4 – 6 VDC
MicroM Series	4 -10 VDC
MicroM Series w/display	10 Minimum 20 – 80 Normal

HONEYWELL CONTROLS

RA890 Series	2 – 6 UA DC
R4795 Series	2 – 6 UA DC
R7795 Series	2 – 6 UA DC
R4140 Series	2 – 6 UA DC
R4150 Series	2 – 6 UA DC
BC7000 Series	2 – 6 UA DC
RM7890 Series	1 ¼ - 5 VDC
RM7895 Series	1 ¼ - 5 VDC
RM7840 Series	1 ¼ - 5 VDC
RM7800 Series	1 ¼ - 5 VDC

**Use these in good health.
Eddy**

Emerson Boiler, Inc.

6081 N 57th Dr.

Glendale, AZ 85301

623-847-4788 Phone 623-847-2386 Fax

Web page www.boilersmadesimple.com or www.emersonboiler.com

E-mail EBBOILERMIKE@AOL.COM